

## MC-174 assembly instruction

1. Put front fender fix on the front shock absorber
2. Use front axle and nut, fix the front wheel
3. Fix the front disc pump with front disc



4. fix handlebar on the front of frame, fixed by bolt M10X45 and lock sleeve.
5. Put front cover assy on the front of scooter with Screws. Fix well with the toolbox and fix the speedometer decoration.
6. Fix rear mirror
7. Fix windshield on the front cover with flat head bolt



8. Fix rear box up part and bottom part by box pin
9. Fix side box outer part and inner part by box pin, assemble the side box lock, fix side box bracket on the side box and connect with scooter.
10. Fix rear rack: first put side box bracket, then put rear rack on the bracket, use bolt fixed. Then fix rear box bolts and nuts on the rear rack.



11. put battery water into the battery, connect anode and cathode with bolts, put into battery box under seat, then assemble battery cover with screw, in corresponding position.

